

Package Contents

Recommended Installation Tools (Not Included)

Qty	Item Description
1 Set of 2	Ultra HZ Rails
1	#2 Phillips Bit 2"
7	Drywall Anchors
7	1.25" Wood Screws
2	Extension Couplers
5	Rail End Caps
4	Extra Rubber O-rings
1	10MM Nut Driver
7	Screw Hole Caps

Tape Measure
Level
Pencil
Electrical Drill
Stud Finder

Thank you for your purchase, please feel free to contact us for customer support at 1-800-611-8644

Recommended Fastener Applications:

Drywall Anchors (Included) - Use for installing rails to drywall if studs are not present in the desired location. Do not use drywall anchors to secure into a wall stud location.

Wood Screws (Included) - Use wood screw to secure rails to wall studs or wood panels, do not use on drywall without securing to a stud. Concrete or Masonry applications not recommended.

Concrete, Brick or Stucco (Not Included) - 3/16" x 1-1/4" Masonry Screw or #8x1-1/4" screw with the proper concrete anchors.



Important! Before Installing Rails do the following:



- 1 Check the Package Contents for missing or damaged items
- 2 Before Installation secure pegs on rails by using the 10MM Nut Driver provided until secure
- 3 Measure wall space to account for rail distance requirements, see Step 5 & 7 for configuration

Contact Customer Service at 1-800-611-8644 for questions or concerns

- Step 1** Use Stud Finder to map mounting locations
- Step 2** Place Rails against walls in desired location
- Step 3** Use Pencil & Level to mark mounting holes, use wall anchor if stud is not available
- Step 4** Drill Anchor into wall and then mount rail with wood screw, otherwise directly mount rail into stud with wood screw
- Step 5** HZ Distance requirement is **3" Max** center space between rails, or **4" Max** from center to center of screw locations. (Same distance)
*Bottle must be level (no tilt) to be supported
- Step 6** If you are extending rails vertically repeat steps 2-5. Use extension couplers to connect rails
- Step 7** If you have multiple sets to create horizontal displays, the minimum space between rail sets is 9"
- Step 8** Add the finishing touch by inserting Endcaps and Dome caps, congratulations you have completed your Ultra Rack Installation!

