

# **ELITE KIT RACK ASSEMBLY INSTRUCTION**


#### 750ml CURVED CORNER Section 3 Complete



Thank you for purchasing Elite Kit Rack by Genuwine Cellars. The following instructions will help you assemble the 750ml CURVED CORNER. Assemble will broken down into three sections.

#### Please study the instructions carefully prior to starting the assembly.





## **HARDWARE**

The following hardware is included in all kits: (QUANTITY WILL VARY, DEPENDING ON KIT.)



Drywall Anchors (QTY: 6)



#8 Robertson Screws (Square Head) (QTY: 6)



Angled Brackets (QTY: 6)



#6 Robertson Screws (Square Head) (QTY: 6)

## **TOOLS REQUIRED**


The following tools are required (NOT INCLUDED):

#### IMPORTANT!

Always follow the manufacturer's instructions on how to use the nail gun, to prevent injury. Genuwine Cellars in not liable for any injury incurred while assembling the kit.




Robertson Screwdrivers #6 & #8 (Square Head)



We Recommend A 21 Gauge Nail Gun (Use 21 gauge brand nails, with appropiate air compressor or electric nailer set to 80psi, to prevent spliting)

## **COMPONENTS**

The following components are included in the 750ml CURVED CORNER.



(QTY: 5)

2 - Right Ladder 2130 (QTY: 5)



129 3c - Back Spacer Bars 120 (QTY: 10)



3b - Back Spacer Bars 112 (QTY: 15)



4 - CC Back Spacers (QTY: 20)



6a - Tilt Stop Edge 129 (QTY: 2)



7a - Crown Mould Edge 129 (QTY: 2)



8a - Base Mould Edge 129 (QTY: 2)



5 - Back Bottle Stop Upright (QTY: 3)


6b - Tilt Stop Center 129 (QTY: 3) 7b - Crown Mould C (QTY: 3)




7b - Crown Mould Center 129 8b - Base Mo




8b - Base Mould Center 129 (QTY: 3)








With the help of another person, turn the rack so the front is on the floor, and the back is facing up. Starting from bottom and work your way up, place the back spacer bars (3b) according to the ladder notches. Make sure to carefully interlock the spacer bars to the ladders.




From the front and bottom of the rack, firmly apply pressure to lock in the joints. Then apply two nails with a nail-gun, to each joint. Remember to firmly lock each joint.

STEP




STEP

While the three middle columns are still laid down, apply the back bottle stop upright (5). Place the back bottle stop upright into the back spacer bar notches as shown.




Flush the back bottle stop upright to the bottom of the rack. Push down and hold firm. Apply two nails with a nail-gun at each joint.



### **SECTION 3: Complete**


Stand the racks up. Make sure bottoms are on the floor, left column on the left, right column on the right, and left-over columns are in the middle. Make sure the left and right column form a 90 degree, as shown. Place the front edge together, and space the back evenly. (Note: Ensure all angle bottle displays are facing front)




STEP

Starting at the middle height, place the CC back spacers (4) between the columns as shown.









STEP

Firmly hold the spacer in place, and apply two nails at each end of the CC back spacer. Do the same to the rest.







STEP

Once the middle height spacers are done, work your way down the racks, one level at a time.

Middle Down

