

Vino Series Post System with Angle Bracket

Installation guide for Vino Series Post with FCP-ANG Brackets




3D INTERACTIVE INSTRUCTIONS

USE BILT TO ASSEMBLE WITH CONFIDENCE

For fast 3D step-by-step instructions,
download the free BILT app!



Available on most iOS and Android Devices



Included:

- (1) Angle Bracket
- (1) Drill Bit
- (1) Self Drilling Screw

Vino Series Post

(sold separately)

- (1) 62" Post Bottom (c-Channel)
- (1) 62" Post Top
- (1) Mounting Base

Additional Components:

(sold separately)

- 96 Mounting Plate screws
- Vino Series Post Mounting Plates with Self-Drilling Screws
- Vino Pins or Vino Rails

Required Tools:

- Drill
- Phillips head drill bit

- Phillips head screwdriver
- Level
- Pencil or Marker
- Tape measure
- Metal cutting saw
- Metal file
- Square
- Adjustable Square
- Rubber Mallet (optional)

Important Note:

These installation instructions will assist you with installing the VintageView Vino Series Post System with an Angle Bracket to allow for an installation on angled surfaces, up to 35 degrees. Angle Brackets can be added to one or both ends of a Vino Series Post.

If your Vino Series Post features welded Base Plates, visit www.vintageview.com/welded

Fasteners:

Fasteners for securing Mounting Plates to the Vino Series Posts are provided (self-drilling screws). Each mounting Plate is pre-drilled for installing Post. When installing finished Vino Series Post to the floor or ceiling, please use the following recommendations for fasteners (not included):

Guidelines for Floor/Ceiling Hardware

Wood/Stud: #8 x 1-1/4" course thread screws (or longer)

Concrete, Brick, or Stucco: 3/16" x 1-1/4" masonry screw
or #8 x 1-1/4" screw with appropriate size expanding anchor

Drywall: Expanding hollow wall anchors with at least #8 screw size






Figure A

1. IDENTIFY PROPER HARDWARE

Using the chart on the previous page, identify the proper floor/ceiling hardware (not included) that will be needed for your specific project. For drywall surfaces in floor or ceiling, VintageView recommend installing to joists or wood backing when available.

2. MEASURE ANGLE & HEIGHT

Measure the desired location's ceiling height from where the front of the Post (its highest point) will set. Subtract 1/8" (3.5mm) from the overlap to account for height of Angle bracket (1/4" [7mm] if using two Angle Brackets) Measure the ceiling angle using an Adjustable square (Figure A).

3. INSERT MOUNTING BASE

Insert (1) Mounting Base into the open end of the Post Bottom Piece (with c-channel). Mounting Base must be fully inserted into the Post Bottom. Base may be oriented perpendicular or parallel to the Wine Racking.

Secure the Mounting Base into the Post Bottom with (2) self-drilling screws through the pre-drilled holes (Figure B).

4. MARK THE POST

Lay the connected Post section next to the Post Bottom, interlaced (Figure C). Position the two sections so that the measurement from top to bottom of the base plates equals your measurement from Step 2. Use a pencil or marker to mark any overlap on the bottom of the connected Post Top.

Turn the post on its side and, using the Adjustable Square, draw a cut line at desired angle from the mark (Figure D). Do not cut from the end with the C-Channel.

4. CUT THE POST

Using a Metal Cutting Saw, cut off the welded Mounting Bracket from the Post Top section at the marked angle (Figure E). *Do not use abrasive saws as they may damage the finish.*




Figure B



Figure C




Figure D




Figure E

5. INSERT ANGLE BRACKET

Insert the Angle Bracket into the Post Top (Figure F, next page). When inserting, position so the Tube of the Angle Bracket goes into the lower side of the Post. The Angle Bracket will fit square in the Post when installed.






Figure F




Figure G

6. SECURE THE BRACKET

Using the provided Drill Bit, drill through Post and Angle below the connection and on the front or back of the Post. Thread provided Screw to secure the Angle Bracket.

7. CONNECT THE POST

Slide the completed Post Top Section onto the C-Channel in the Post bottom (Figure G). It may require a Rubber Mallet to connect fully.




Figure H

8. MARK MOUNTING HOLES

Place the Post in the desired location. Ensure it is plumb with a level and mark the mounting holes on the ceiling and floor. Set Post aside.

9. MARK MOUNTING PLATE HOLES

Lay the first wine rack Mounting Plate in the desired location on the Post. Mark two (2) mounting hole locations. Mark the holes for the next Plate ensuring a minimum of 3-3/4" vertical clearance from one Plate to the next (Figure I). Use a Level and a Square to ensure Plates are Level. Set the plate to the side.




Figure I

NOTE: Plates can be installed to one, two, three, or four sides of the Post with an Angle Bracket. If consecutive Plates are assembled on adjacent sides, a minimum of 3-3/4" v(96mm) vertical clearance is required (Figure I).

10. PRE-DRILL MOUNTING HOLES

Using the provided Drill Bit, pre-drill all marked mounting hole locations.

11. ASSEMBLE/INSTALL THE PLATES

For Vino Pins

Mounting Plates are sold in two unique widths: one for standard 750ml or Champagne bottles and one for magnum 1.5L bottles.

(Optional) Assemble the Vino Pins and Vino Pins Extensions (Figure J) to reach desired bottle depth (up to 3 bottles deep for 750ml bottles and up to 2 bottles deep,




Figure J

with spacer, for Magnum bottles.

Fasten the Vino Pins to the Mounting Plates using provided M6 Screws (Figure K, next page). Ensure the higher mounting hole in the Mounting Plate points in the direction you want the bottle neck to face. Fasten the Vino Pins Neck (slimmer bottle impression) piece to the higher of the two holes.






Figure K




Figure L

For Vino Rails

Mounting Plates are sold in standard 750ml or Champagne bottles and magnum 1.5L bottles configurations, each with choice of single, double, or triple bottle width. Thread all Vino Rails to the Mounting Plates using the provided M6 Screws (Figure L).

NOTE: If installing Vino Rails Magnum wine racks, do not insert supplied Bridge until the entire installation is finished.




Figure M

12. INSTALL THE PLATES

Attach one (1) assembled Mounting Plate to the Post using two (2) provided Self-Drilling Screws into the pre-drilled holes (Figure L). Repeat the previous step to attach the remaining Mounting Plate assemblies (Figure M).




Figure N

13. INSTALL THE SYSTEM

Stand the Post Assembly in the desired location and ensure it is plumb both front and back and side-to-side with a level. Mark mounting holes on floor, ceiling, and wall. Set Post aside and pre-drill mounting holes.




Figure M

Place Post back in place, ensuring it is level, and secure to the ceiling (Figure N) using two (2) of the appropriate fasteners (not provided). Double check the Post is plumb and secure the Post to the floor using two (2) of the appropriate fasteners (not provided).

If any of the Mounting Plates appear unlevel, loosen one (1) Screw slightly and reposition using a Rubber Mallet and Level (Figure O). Re-tighten the screw.

14. ADD WINE

Only the good stuff.

Problems?

Try using BILT 3D intelligent instructions, visit www.vintageview.com or call 303-504-9463.

Maintenance and Care:

Vino Pins or Rails should be regularly checked for tightness. If

any rack is loose, tighten by hand until secure. Components of the Vino Series Post System may be cleaned with a dust cloth or rubbing alcohol. Abrasive pads or cleaning supplies should NOT be used as they will damage the finish.

SCAN FOR BILT: 3D INSTRUCTIONS



POWERED BY BILT INTELLIGENT INSTRUCTIONS®

